



WEATHERBEATER™ FLOOR LINERS

PT #19321

CARE AND USE INSTRUCTIONS

Thank you for selecting a WeatherBeater™ Floor Liner from Husky Liners. Your new third seat liner is custom molded to fit your Ford Explorer. The liner is made to take the place of your factory floor mats. **For correct fit, it is necessary to remove the factory floor mats before installing your new floor liners.** However, do not remove the factory-installed carpeting.

Your liner is made from an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liner is with a damp cloth or sponge. If using a cleaner, 409® or Glass Plus® work well. Use of Armor All®, Son-of-a-Gun® or similar items is discouraged as these products make the liner slick.

INSTALLATION INSTRUCTIONS FOR YOUR FORD EXPLORER THIRD SEAT FLOOR LINER



TO EASE INSTALLATION OF YOUR THIRD SEAT LINER, FIRST MOVE FORWARD / FOLD DOWN THE SECOND ROW SEATS. THIS WILL GIVE EASY ACCESS TO THE THIRD ROW FLOOR PAN. NEXT, INSTALL THE LINER, ORIENTING IT AS SHOWN ABOVE. ONCE YOU HAVE INSTALLED YOUR LINER, REPOSITION THE FRONT SEATS AS DESIRED.