



X-ACT CONTOUR

FLOOR LINERS

CARE AND USE INSTRUCTIONS P/N 53151

Thank you for selecting a X-act Contour® Floor Liner from Winfield Consumer Products. Your new center hump liner is custom molded to fit your Chevrolet Silverado/GMC Sierra Extended and Crew Cab trucks. The liner is made to take the place of your factory floor mat. ***For correct fit, it is necessary to remove the factory floor mats before installing your new floor liner.*** However, do not remove the factory-installed carpeting.

Your liner is made from an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liner is with a damp cloth or sponge. If using a cleaner, 409® or Glass Plus® work well. Use of Armor All®, Son-of-a-Gun® or similar items is discouraged as these products make the liner slick.

CHEVROLET SILVERADO & GMC SIERRA DOUBLE CAB AND CREW CAB TRUCK CENTER HUMP LINER INSTALLATION INSTRUCTIONS

FRONT OF VEHICLE

