



X-ACT CONTOUR® FLOOR LINERS

PT #54151

CARE AND USE INSTRUCTIONS

Thank you for selecting a X-act Contour® Floor Liner from Husky Liners. Your new 3rd seat liner is custom molded to fit your specific vehicle. The liner is made to take the place of your factory floor mat(s). **For correct fit, it is necessary to remove the factory floor mats before installing your new floor liner.** However, do not remove the factory-installed carpeting.

Your liner is made from an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liner is with a damp cloth or sponge. If using a cleaner, 409® or Glass Plus® work well. Use of Armor All®, Son-of-a-Gun® or similar items is discouraged as these products make the liner slick.

INSTALLATION INSTRUCTIONS FOR YOUR X-ACT CONTOUR 3RD SEAT FLOOR LINER



TO INSTALL YOUR THIRD SEAT LINER, FIRST MOVE YOUR SECOND ROW SEATS COMPLETELY FORWARD. THEN, INSTALL YOUR NEW LINER, POSITIONING IT IN THE VEHICLE AS SHOWN ABOVE. LASTLY, REPOSITION YOUR SECOND ROW SEATS AS DESIRED.



X-ACT CONTOUR® FLOOR LINERS

PT #54151

CARE AND USE INSTRUCTIONS



A TRIM GROOVE IS PROVIDED TO REMOVE THE WALKWAY PORTION OF THE FLOOR LINER TO ACCOMMODATE VEHICLES THAT HAVE A 2ND ROW BENCH SEAT.