



X-ACT CONTOUR

FLOOR LINERS

CARE AND USE INSTRUCTIONS – PN:5481

Thank you for selecting X-act Contour™ Front Floor Liners from Husky Liners Inc. Your new front floor liners are custom molded to fit your specific vehicle's floor board. The liners are made to take the place of your factory floor mats. **For correct fit, it is necessary to remove the factory floor mats before installing your new floor liners.** However, do not remove the factory-installed carpeting.

Your liners are made from an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liners is with a damp cloth or sponge and soap and water. Windex®, 409® and ArmorAll® type cleaners work as well.



LEFT OR DRIVER



RIGHT OR PASSENGER

TO INSTALL YOUR NEW LINERS, POSITION THEM IN THE FLOOR PANS AS SHOWN ABOVE. THE DRIVER'S SIDE LINERS ATTACH TO THE FACTORY FLOOR MAT RETAINING POSTS. ALIGN THE LINERS OVER THE POSTS AND PRESS DOWN IN THE AREA ABOVE THE POSTS TO SNAP THEM INTO PLACE.