

# INSTALLATION INSTRUCTIONS

**⚠ WARNING: DO NOT EXCEED PRODUCT RATING OR TOW VEHICLE LAMP LOAD RATING, WHICHEVER IS LOWER**

## APPLICATIONS

Make	Model
Lexus	RX 330
Lexus	RX 350

## CUSTOM WIRING HARNESS



## WIRING LOCATION GUIDE

### SUVs, MINI & FULL-SIZED VANS (S)

Representative vehicle shown below

**S3** - Behind driver side rear access panel

**S4** - Behind passenger side rear access panel



## NOTICE

All steps must be followed to ensure the wiring harness will function properly. Once installed, test for proper function by using a test light or connecting a properly wired trailer.

## TOOLS NEEDED

Phillips screwdriver	Wire stripper
Flat blade screwdriver	Wire crimper
Panel trim removal tool	Cutting tool

## ⚠ WARNING

The battery connection must be fuse-protected, 10-amp max. Exceeding the product rating can cause loss of warranty, overheating and potential fire. Do not exceed product rating or tow vehicle lamp load rating, whichever is lower.

**Signal Circuits** - 3.0 amps per side

**Tail / Running Circuits** - 6.0 amps total

Check vehicle owner's manual or contact the vehicle manufacturer for more information.

# INSTALLATION / SAFETY INSTRUCTIONS

## Step 1

Locate and remove the small access panels found on the interior trim panels on both sides of the vehicle. Carefully remove the rear hatch threshold plate.

## Step 2


Behind the removed access panels locate the vehicle taillight wiring harness connectors. The connectors will be similar to those on the custom wiring harness. Starting on the driver side, separate the connectors from the taillight housing taking care not to damage the locking tabs.

## Step 3

Insert the custom wiring harness end with yellow wire between the separated connectors. Make sure the connectors are fully inserted with locking tabs in place.

## Step 4

Locate a suitable grounding point near the connector such as an existing screw with nut in the vehicle frame or drill a 3/32" pilot hole for the provided screw. The area should be free of rust, dirt and paint. Secure the white ground wire using the ring terminal and provided screw.

 **WARNING:** Check for miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and / or personal injury.

## Step 5

Route the custom wiring harness end with the green wire to the passenger side behind the removed trim panels. Repeat steps 2-3 on the passenger side using the harness end with the green wire.

## Step 6

Locate a flat spot inside the vehicle, near the taillight. Adhere the black converter box using the provided double-sided tape.

## Step 7

Route the black power wire from the vehicle battery as shown on the included CME-PCL-INS sheet.

## Step 8

When in use, route the 4-flat to the center of the vehicle and out of the trunk. When not in use, roll up and store in a convenient, out of the way location inside the trunk. Secure any loose wires with the provided cable ties.

## Step 9

Install the 10-amp fuse in the in-line fuse holder.

## Step 10

Reinstall all items removed during install. Install the provided 4-flat dust cover to help prevent corrosion.