

**CLASS A MOTORHOME BUG SCREEN
BY**



**DS409
INSTALLATION INSTRUCTIONS**

Enclosed are: -Bug screen
-Installation kit with Stick-A-Stud™ Fasteners, hooks & shock cord, alcohol swab

FOR BEST RESULTS, INSTALL AT TEMPERATURES OVER 60°F (16°C)

Stick-A-Stud™ Fasteners are designed to shape to the contours of the motor home. Certain installations may require bending or contouring the base of the Stick-A-Stud™ Fastener. (see below)

WHEN INSTALLING STICK-A-STUD™ FASTENERS, FIRM PRESSURE MUST BE APPLIED TO ENSURE PROPER CONTACT.

- Step 1:** Snap all Stick-A-Stud™ Fasteners to the bug screen while ensuring the protective backing remains intact.
- Step 2:** Position the bug screen on the motorhome and note where each Stick-A-Stud™ Fastener will be located. Ensure there will be maximum contact at each installation point.
- Step 3:** Temporarily fasten the bug screen with masking tape to the motorhome. Ensure the bug screen is secure across the motorhome without causing stress or pressure on the bug screen.

CAUTION: A MINIMAL AMOUNT OF STRESS ON THE BUG SCREEN FROM SIDE TO SIDE AND TOP TO BOTTOM IS RECOMMENDED. EXCESSIVE STRESS WILL CAUSE IMPROPER INSTALLATION.

At this point it is important to note that the surface contact points may vary as below:

- Step 4:** Clean, with the alcohol swab provided, all contact points where the Stick-A-Stud™ Fasteners will be applied. Ensure no wax or cleaning fluid is present. Ensure contact points are dry.
- Step 5:** Remove the protective backing from a corner Stick-A-Stud™ Fastener and immediately apply to the surface. Apply firm pressure for 20 seconds.

NOTE: REMOVE THE PROTECTIVE BACKING ONE AT A TIME WHEN APPLYING STICK-A-STUD™ FASTENERS.

- Step 6:** Apply the next Stick-A-Stud™ Fastener ensuring that no stress or pressure is applied to other fasteners when installing the bug screen.

NOTE: A MINIMAL AMOUNT OF STRESS ON THE BUG SCREEN FROM SIDE TO SIDE AND TOP TO BOTTOM IS RECOMMENDED. EXCESSIVE STRESS WILL CAUSE IMPROPER INSTALLATION.

- Step 7:** Attach remaining Stick-A-Stud™ Fasteners along the top.
- Step 8:** Insert shock cords through grommets from the back of the screen. Tie a knot at the end of the shock cord to prevent it from slipping through grommet.
- Step 9:** Pull the shock cord until the bug screen is snug against the grill and tie a knot.
- Step 10:** Repeat steps 8 & 9 for remaining hooks.

CAUTION: HOLD “S” HOOKS FIRMLY WHEN INSTALLING THE BUG SCREEN TO PREVENT HOOKS FROM SPRINGING LOOSE.

- 1) Stick-A-Stud™ Fasteners are designed to snap apart in two ways:

- 2) If required, Stick-A-Stud™ Fasteners may be removed by applying alcohol solution to loosen the adhesive.
- 3) Stick-A-Stud™ Fasteners may be purchased separately – Part #HK104.

Should you require additional information on installing this product, please contact our customer service department.

CAUTION: COVERING VEHICLE HEADLIGHTS AND LICENSE PLATE MAY BE ILLEGAL IN SOME STATES AND PROVINCES. PLEASE CHECK LOCAL, STATE OR PROVINCIAL LAWS.



Fia Inc, Winnipeg, Canada R3L 0N3 Phone (204) 475-0515 Toll-free: 1-800-835-0438
Fax (204) 284-8246 E-mail: info@gofia.com Web Site: www.gofia.com