

LOCK'ER DOWN



Security Products

Instructions for Model 2011 X with USB extension

1. If you have a combination lock, it is easier to set the combination before installing the safe.
2. Open console and remove rubber pad in the floor of console.
3. There are 4 screws holding down the console, remove all four.
4. Put the lid assembly in as shown in Fig 1, turn and pull up to top.
5. Put in right side plate sliding it under USB cable and attach nuts.
6. put in left side plate and attach nuts.
7. Put in rear piece and put screw in left rear console screw hole.
8. Put in front panel and attach to left front screw hole.
9. Finally place connector strap between front and rear plates and tighten all fasteners.

Installation Video



Enjoy your purchase.

Each part is described on back.



Top Assembly



Right Side Plate



Left Side Plate



Front Plate



Rear Plate



Front—Rear Connector



Front Assembly View



Rear Assembly View

