

LOCK'ER[®] DOWN

Security Products

Instructions for Model 3026X SUVault[®]

1. If you have a combination lock, it is easier to set the combination before installing the safe.
2. Near the opening of the left rear door of the crew cab is a bolt holding down the seat, with another over past the mid-point of the seat.
3. To install, remove the bolts and retain for reattachment.
4. Install each bracket without using the cover bracket at this time. Place the included washer in the recess of the seat bracket and place the bracket over the hole and replace bolts but don't tighten at this point.
5. Place the safe in the vehicle allowing the studs in the brackets to enter the slots in the rear of the safe.
6. Place the nuts on the studs and semi tighten. Make sure the vehicle door closes without hitting the safe. With the safe still bolted in, tighten the bolts holding the bracket down to the floor.
7. Remove the safe, sliding it forward and place the bracket covers over the brackets and reattach the safe to the brackets.

