

Hardware:	Qty	Parts Included:	Qty
M8 x 25mm hex bolt	2	RBS-H Bumper	1
M8 washers	4	Bumper Bracket	2
M8 Nuts	2	Bracket spacers	4
1'x1/2" Hex bolts	4		
1/2" nuts	4		
1/2" Washers	8		

Rear Bumper Removal:

Step 1: Unplug the connector that connects the bumper's wiring harness to the rest of the vehicle.



Step 2: Unplug the connector on the back of the trailer light plug. Press the two metal tabs together and push it out of the front of bumper.



Step 3: Remove the license plate bulbs from there housing and secure up out of the way.

Step 4: Unbolt and remove the license plate and plastic retainer from the OE rear bumper.




Step 5: Remove the plastic end cap. (Both sides)



Step 6: Remove the plastic bumper cap and set aside.



Step 7: Remove the four top bolts and two lower bolts that attach the bumper end and Remove. (Both sides)




RBS-H Bumper Bracket Install:



Step 1: Remove the two 19mm hitch bolts. (Both Sides)



Step 2: Remove the two bolts that attach the OE bumper bracket and remove (Bothe sides))




Step 3: Using the two 21mm hitch bolts removed in step 1 and the supplied M8x25mm Hex bolt, nut and washers, install the bumper brackets with the spacers and tighten. (Both Sides)



RBS-H Bumper Install:

Step 1: Remove RBS-H bumper skid plate and set aside. Next, install the RBS-H bumper to the bumper brackets using the supplied 1/2"x1" hex bolts, nuts and washers.



Step 2: After proper alignment, tighten all hardware. **NOTE: Carefully open tail gate to check clearance with bumper before final tightening.**

Step 3: Re-Install RBS-H skid plate and secure. **NOTE: An aftermarket license plate light is recommended.**