

Quick and Easy Installation Instructions

CONTENTS

- (2) front visors
- (2) rear visors (if applicable)
- (2) or (4) alcohol pads - depending on application
- (1) instruction sheet

IMPORTANT: Read all instructions carefully before beginning the installation. This instruction sheet is for both 2 & 4 door models. The visors mount on the **OUTSIDE** of the door frame. The ideal installation temperature is between 65°-110°F (18°-43°C).

..... **Helpful Hint**
 A trial fit is recommended to ensure proper positioning, since installing and then removing the Ventvisor will degrade the adhesive performance of the tape.

STEP 1

Clean the trim/mirror cap where the visor will mount with an alcohol pad and wipe dry. See **FIGURE 1**

STEP 2

Remove the tape liner from the front and rear end flanges. To reduce the risk of tape contamination due to improper positioning, expose only 2" (5cm) of tape from each end of the lateral flange by peeling back liner. See **FIGURE 2**

STEP 3

Align the driver side visor with the previously cleaned areas. Press the exposed areas of tape against the surfaces and verify position. Be sure the front end flange is properly positioned over the mirror cap. See **FIGURE 3**

STEP 4

With the visor in its final position, remove the remainder of the tape liner by pulling on the free ends. Run your finger along the visor flanges to ensure proper adhesion of the tape to the trim/mirror cap.

4-Door installation proceed to STEP 5

STEP 5

Repeat the above installation procedure for the rear visor. See **FIGURE 4**

Repeat the above **STEPS** for opposite side visors.

