

WINDSHIELD FILM INSTALLATION GUIDE



TOOLS AND SUPPLIES NEEDED

1. Pre-cut windshield guard
2. Spray bottle with slip solution
(water + a few drops of baby shampoo/dish soap)
3. Microfiber towels
4. Hard card or plastic edge wrapped in
microfiber or paper towel
5. Razor blade or utility knife (optional
for trimming)
6. Hair Dryer/ Heat Gun (optional)
7. Handled Squeegee (optional)
8. Nitrile gloves (optional)

1. Preparation

- Park in a shaded, dust-free area.
- Clean the windshield thoroughly — remove bugs, sap, and any dirt. Use glass cleaner and finish with isopropyl alcohol.
- Wash your hands or wear gloves to prevent fingerprints.

2. Wet the Windshield

- Spray the entire windshield generously with the slip solution. This prevents the film from sticking too quickly.

3. Remove the Liner

- Peel the backing off the windshield guard. As you do, spray the adhesive side with slip solution to reduce static and ease placement.

4. Position the Film

- Lay the wet adhesive side of the guard onto the wet windshield.
- Align it carefully with the corners and edges of the windshield. The solution will allow you to slide it into place until you are ready to lock down with a hard card/squeegee

5. Squeegee / Hard Card from Center Out

- Re-spray the top of the film if needed to reduce friction and avoid scratching.
- Begin squeegeeing from the center outward in overlapping strokes, pushing out air bubbles and excess solution. (Press down hard when squeegeeing-film is pressure activated)

PRO TIP

Remove freedom panels and stand inside jeep for better leverage.

PRO TIP

If film is not laying flat and bunching at the bottom you can use a hair dryer to "shrink up the film" (we sometimes see this with non oem replacement)

6. Detail Edges & Corners

- Use a wrapped hard card to press down the edges of the glass. You may need to go back over edges multiple times.
- If necessary, trim any slight overhangs with a razor blade (carefully and with a stainless-steel blade).

PRO TIP

Use a hair dryer or heat gun to speed up the drying process.

7. Final Inspection

- Wipe the surface with a clean microfiber towel.
- Let the vehicle sit for 6-8 hours without windshield wiper use or heavy rain for best adhesion.
- Small bubbles, hazing, and moisture is normal while film is drying.

PRO TIP

Heat from the sun can help with drying time.



AFTERCARE TIPS

- Don't go through a car wash for 72 hours.
- Avoid using abrasive cleaners.
- Use a soft microfiber towel to clean the windshield guard.
- Keep wipers clean and free of debris



[BUYSCORPION.COM/PAGES/WINDSHIELD-FILM](https://buyscorpion.com/pages/windshield-film)