SEAT COVERS





SUPER-GRIP®

THE SLIP RESISTANT FASTENING SYSTEM

INSTALLATION INSTRUCTIONS FOR NP92-89/ OE32-89/ SL62-89/ SP82-89/ TR42-89/ TRS42-89

Thank you for purchasing one of our fine quality products. Your seat cover is engineered from high quality materials and designed with precision to give you a long-lasting, well-adjusted fit.

BACKREST COVER 40 side:

- 1) Remove headrest (see note below)
- 2) Unlatch backrest from back wall
- 3) Slip cover over backrest

- 4) Tuck flaps through crevice under backrest
- 5) Fold down backrest and attach velcro on carpet strips
- 6) Replace headrest (see notes)

BACKREST COVER 60 side:

- 1) Remove headrest (see note below)
- 2) Unlatch backrest from back wall
- 3) Slip cover over backrest under center seat belt
- 4) Smooth cover tightly from top to bottom
- 5) Install adhesive back velcro (included) on inside edge of armrest well
- to align with velcro on seat cover. NOTE: BEFORE SECURING
- VELČRO, CLEAN AREA WITH ALCOHOL SWAB PROVIDED.
- 6) Tuck flaps through crevice under backrest
- 7) Fold down backrest and attach velcro on carpet strips
- 8) Replace headrest (see notes)

C) CUSHION COVERS X 2:

- 1) Center cover on seat
- 2) Tuck back flap into crevice
- 3) Ensure the slit is in line with car seat hook up (40 side & 60 side); center seat belt buckle (60 side only)
- 4) Lift seat in up position

- 5) Pass the back straps under seat and buckle to front of cover
- 6) Apply side velcro under seat carpet
- 7) Pass side straps on cover under seat and buckle
- 8) Adjust straps and velcro to equalize tension

D) ARMREST COVER

1) Fold down armrest

- 2) Slip cover over armrest and attach velcro
- 3) Tuck cover under plastic cup holder trim for cleaner look

NOTES:


1) SELF-LOCKING SUPER-GRIP® BUCKLE:



2) HEAD REST REMOVAL:

Push in side release buttons Lift off

(If unable to remove consult dealership)



- 3) RE-INSTALLATION OF HEADRESTS
- A) Ensure pre-cut holes in seat cover align with holes in headrest base.
- B) Replace headrests

WARNING: SEATS WITH INTEGRATED SEAT AIRBAGS MUST BE COVERED ONLY WITH SEATCOVERS DESIGNED WITH OPENINGS THAT WILL NOT INTERFERE WITH THE DEPLOYMENT OF THE AIRBAG. NEVER INSTALL SEAT COVERS WITHOUT THESE OPENINGS AS THIS MAY INTERFERE WITH THE PROPER DEPLOYMENT OF THE AIR BAGS AND COULD RESULT IN SERIOUS INJURY.

Fia Inc. Winnipeg, Canada R3L 0N3 Telephone (204) 475-0515 Toll-Free: 1-800-835-0438 Fax: (204) 284-8246 E-Mail: info@gofia.com Website: www.gofia.com

LIMITED 2 YEAR WARRANTY

Fia Inc. guarantees the original purchaser a limited 2 year warranty against manufacturer's defects in materials, workmanship and finish under normal use. The warranty is void if the product has been damaged resulting from product misuse, improper installation, product modifications or product neglect. The warranty applies to all Fia products and is limited to repair or replacement of the product. Warranty does not include cost of removal, installation, labor, freight and incidental or consequential damages.

Original purchaser must return defective merchandise along with the original purchase receipt to the original place of purchase for repair or replacement. Shipping charges will apply for any repair or replacement.

Buyer assumes all risk and liability whatsoever from the installation of Fia products. Vehicles equipped with supplemental restraint systems (air bags) deployed by impact should not be modified or covered by any aftermarket seat cover without consulting the vehicle manufacturer and Fia Inc. Fia Inc. assumes no liability for injury, loss, incidental or consequential damages in the event of an accident.

Fia Inc. Winnipeg, Canada R3L 0N3 Telephone (204) 475-0515 Toll-Free: 1-800-835-0438 Fax: (204) 284-8246 E-Mail: info@gofia.com Website: www.gofia.com