If you have any comments or concerns, please feel free to contact our customer service department at: Toll-free: 1-800-835-0438

OR

Email: info@gofia.com

SEAT COVERS



SUPER-GRIP®

THE SLIP RESISTANT FASTENING SYSTEM

INSTALLATION INSTRUCTIONS OE32-91/ SL62-91/ SP82-91/ TR42-91

Thank you for purchasing one of our fine quality products. Your seat cover is engineered from high quality materials and designed with precision to give you a long-lasting, well-adjusted fit.

BACKREST COVER 40 side:

- 1) Remove headrests (see note below)
- 2) Undo belt buckle from elastic holder
- 3) Detach velcro closure on cover
- 4) Slip cover over backrest
- 5) Attach velcro closure on cover

- 6) Tuck flaps through crevice under backrest
- 7) Fold down backrest and attach flaps on velcro at back of cover
- 8) Replace belt buckle on elastic on cover
- 9) Replace headrests (see notes)

BACKREST COVER 60 side:

- 1) Remove headrests (see note below)
- 2) Undo belt buckle from elastic holder
- 3) Detach velcro closure on cover
- 4) Slip cover over backrest under center seat belt
- 5) Attach velcro closure on cover

- 6) Tuck flaps through crevice under backrest
- 7) Fold down backrest and attach flaps on velcro at back of cover
- 8) Replace belt buckle on elastic on cover
- 9) Replace headrests (see notes)

CUSHION COVERS X 2:

- 1) Center cover on seat
- 2) Tuck back flap into crevice
- 3) Ensure the slit is in line with car seat hook up
- 4) Lift seat in up position

- 5) Bring each end of strap sewn across cover under seat and buckle
- 6) Pass the back straps under seat and buckle to front and side of
- 7) Adjust straps and buckle to equalize tension

NOTES:


1) SELF-LOCKING SUPER-GRIP® BUCKLE:



- 3) RE-INSTALLATION OF HEADRESTS
- A) Ensure pre-cut holes in seat cover align with holes in headrest base.
- B) Replace headrests

2) HEAD REST REMOVAL:

- 1) Insert paper clip into hole at base to release
- 2) Push in side release button
- 3) Lift off
- (If unable to remove consult dealership)



WARNING: SEATS WITH INTEGRATED SEAT AIRBAGS MUST BE COVERED ONLY WITH SEATCOVERS DESIGNED WITH OPENINGS THAT WILL NOT INTERFERE WITH THE DEPLOYMENT OF THE AIRBAG.. NEVER INSTALL SEAT COVERS WITHOUT THESE OPENINGS AS THIS MAY INTERFERE WITH THE PROPER DEPLOYMENT OF THE AIR BAGS AND COULD RESULT IN SERIOUS INJURY.

Fia Inc. Winnipeg, Canada R3L 0N3 Telephone (204) 475-0515 Toll-Free: 1-800-835-0438 Fax: (204) 284-8246 E-Mail: info@gofia.com Website: www.gofia.com