SEAT COVERS BY





FEATURING SUPER-GRIP® THE SLIP RESISTANT FASTENING SYSTEM

INSTALLATION INSTRUCTIONS NP95-11/ Oe35-11/ SL65-11/ SP85-11/ TR45-11/ TRS45-11

Thank you for purchasing one of our fine quality products. Your seat cover is engineered from high quality materials and designed with precision to give you a long-lasting, well-adjusted fit.

A) CUSHION COVER

- 1. Center cover on seat
- 2. Tuck back flap through crevice
- 3. Wrap around Velcro on metal bar at back.
- 4. Insert foamed material between plastic molding and base of seat.
- 5. Pull two long straps at the back and buckle.
- 7. Smooth cover and adjust Velcro and straps to ensure a

B) BACKREST COVER - 40 SECTION

- 1. Open all Velcro closures on cover
- 2. Remove headrest (see note below).
- 3. Slip cover over backrest. Place latch handle through opening on cover
- 4. Unlatch backrest and hold down in 3/4 position
- 5. Pass carpet strip on cover through crevice and place backrest in fold flat position
- 6. Pull carpet strip through crevice and apply Velcro.
- 7. Smooth cover from top to bottom. Adjust Velcro if required. Re-install headrest.

BACKREST COVER - 60 SECTION

- 1. Open all Velcro closures and zipper on cover
- 2. Remove headrests (see note below)
- 3. Slip cover over backrest. Place latch handle through opening on cover
- 5. Ensure cover is installed under seat belt
- 6. Unlatch backrest and hold down in \(^3\)4 position
- 7. Pass carpet strip on cover through crevice and place backrest in fold flat position
- 8. Close zipper and pull carpet strip through crevice and apply Velcro
- 9. Place backrest in up position and align stretch fabric material with Velcro supplied inside the armrest well. NOTE: BEFORE POSITIONING VELCRO, CLEAN AREA WITH ALCOHOL SWAB PROVIDED.
- 10. Smooth cover from top to bottom. Adjust Velcro if required. Re-install headrests.

D) ARMREST COVER

1. Fold armrest down

2. Slip cover over armrest and attach Velcro


NOTES:

1) SELF-LOCKING SUPER-GRIP® BUCKLE:



2) HEAD REST REMOVAL:

- Push in side release buttons
- Lift off (If unable to remove consult dealership)



Fia Inc. Winnipeg, Canada R3L 0N3 Telephone (204) 475-0515 Toll-Free: 1-800-835-0438

Fax: (204) 284-8246 E-Mail: info@gofia.com Website: www.gofia.com



LIMITED 2 YEAR WARRANTY

Fia Inc. guarantees the original purchaser a limited 2 year warranty against manufacturer's defects in materials, workmanship and finish under normal use. The warranty is void if the product has been damaged resulting from product misuse, improper installation, product modifications or product neglect. The warranty applies to all Fia products and is limited to repair or replacement of the product. Warranty does not include cost of removal, installation, labor, freight and incidental or consequential damages.

Original purchaser must return defective merchandise along with the original purchase receipt to the original place of purchase for repair or replacement. Shipping charges will apply for any repair or replacement.

Buyer assumes all risk and liability whatsoever from the installation of Fia products. Vehicles equipped with supplemental restraint systems (air bags) deployed by impact should not be modified or covered by any aftermarket seat cover without consulting the vehicle manufacturer and Fia Inc. Fia Inc. assumes no liability for injury, loss, incidental or consequential damages in the event of an accident.

Fia Inc. Winnipeg, Canada R3L 0N3 Telephone (204) 475-0515 Toll-Free: 1-800-835-0438

Fax: (204) 284-8246 E-Mail: info@gofia.com Website: www.gofia.com