If you have any comments or concerns, please feel free to contact our customer service department at:

Toll-free: 1-800-835-0438

OR

Email: info@gofia.com

SEAT COVERS

fia

FEATURING

SUPER-GRIP®

THE SLIP RESISTANT FASTENING SYSTEM

INSTALLATION INSTRUCTIONS FOR

NP97-11/ Oe37-11/ SL67-11/ SP87-11/ TR47-11/ TRS47-11

Thank you for purchasing one of our fine quality products. Your seat cover is engineered from high quality materials and designed with precision to give you a long-lasting, well-adjusted fit.

The Super Grip Buckles are self-locking. For proper usage, see diagram.

BACKREST COVER:

- Move seat to most forward position
- 2) Slip cover over backrest
- 3) Pull cover down firmly over backrest
- 4) Tuck Velcro flaps through crevice and attach to Velcro at back

NOTE: FOR SEATS WITH ARMRESTS – THE BACKREST PORTION OF THE SEAT COVER HAS VELCRO CLOSURES ON THE SIDE SEAMS TO ALLOW FOR FITTING AROUND ARMRESTS.

CUSHION COVER:

- 1) Center cover on the seat
- 2) Pass the front strap under seat and buckle to back
- 3) Pass side straps around the back of seat and buckle
- 4) Adjust all straps and buckles to equalize tension for a uniform fit

WARNING: SEATS WITH INTEGRATED SEAT AIRBAGS MUST BE COVERED ONLY WITH SEATCOVERS DESIGNED WITH OPENINGS THAT WILL NOT INTERFERE WITH THE DEPLOYMENT OF THE AIRBAG.. NEVER INSTALL SEAT COVERS WITHOUT THESE OPENINGS AS THIS MAY INTERFERE WITH THE PROPER DEPLOYMENT OF THE AIR BAGS AND COULD RESULT IN SERIOUS INJURY.

fia

Fia Inc., Winnipeg Canada R3L 0N3 Phone: (204) 475-0515 Toll-Free: 1-800-835-0438 Fax: (204) 284-8246 E-mail: info@gofia.com Website: www.gofia.com