If you have any comments or concerns, please feel free to contact our customer service department at:

Toll-free: 1-800-835-0438

OR

Email: info@gofia.com

SEAT COVERS

**FEATURING** 



THE SLIP RESISTANT FASTENING SYSTEM **INSTALLATION INSTRUCTIONS FOR** 

OE37-23/ SL67-23/ SP87-23/ TR47-23

Thank you for purchasing one of our fine quality products. Your seat cover is engineered from high quality materials and designed with precision to give you a long-lasting, well-adjusted fit.

## **INSTRUCTIONS:**

## A) BACKREST COVER

- 1) Open velcro on the side seam to allow for fitting around armrest
- 2) Slip cover over backrest and pull down firmly
- 3) Fasten side velcro

- 4) Tuck flaps through crevice and attached to velcro at
- 5) Adjust all velcro to equalize tension

## **B) CUSHION COVER**

- 1) Center cushion cover on seat
- 2) Ensure seat belt buckle is through opening provided
- 3) Pass the front strap under the seat and buckle to the back flap of cover
- 4) Pass side straps through the opening between the molded plastic and the seat and buckle to back flap of cover
- 5) Adjust straps and buckles to equalize tension

## **NOTES:**

1) SELF-LOCKING SUPER-GRIP® BUCKLE:



WARNING: SEATS WITH INTEGRATED SEAT AIRBAGS MUST BE COVERED ONLY WITH SEATCOVERS DESIGNED WITH OPENINGS THAT WILL NOT INTERFERE WITH THE DEPLOYMENT OF THE AIRBAG.. NEVER INSTALL SEAT COVERS WITHOUT THESE OPENINGS AS THIS MAY INTERFERE WITH THE PROPER DEPLOYMENT OF THE AIR BAGS AND COULD RESULT IN SERIOUS INJURY.

fia

Fia Inc. Winnipeg, Canada R3L 0N3 Telephone (204) 475-0515 Toll-Free: 1-800-835-0438

Fax: (204) 284-8246 E-Mail: info@gofia.com Website: www.gofia.com

6-21-13