

# 56099

LEXUS HS 250H

## WIRING LOCATION GUIDE GUÍA DE UBICACIÓN DEL CABLEADO IDE D'EMPLACEMENT DES FILS



### MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.

### ¡DEBE LEERSE PRIMERO!

Debe seguirse todos los pasos para asegurar el correcto funcionamiento del Conector-T. Para verificar la correcta instalación, pruebe conectando una luz de prueba o un remolque debidamente cableado.

### À LIRE D'ABORD!

Pour assurer le bon fonctionnement du T-Connector, il faut suivre toutes les étapes. Pour vérifier que l'installation a été bien effectuée, branchez un feu de test ou une remorque correctement filéée.

1/21/2010



## English

1. Open the trunk and remove cargo net and trunk floor covering. [A][B] Remove jack storage tray. [C] Remove the rear scuff panel by removing plastic fasteners holding it in place and pulling up. [D][E] On both sides of the trunk remove plastic fasteners holding the felt trunk liner in place. [F] Behind the felt trunk liner locate the vehicle's taillight wiring harness. [G] The harness will have connectors similar to those on the T-connector harness.

2. Starting on the passenger side of the vehicle separate the connectors being sure not to damage the locking tabs. Insert the T-connector end with the green wire in-between the separated connectors. Make sure the connectors are fully inserted with locking tabs in place.

3. Route the T-connector end with the yellow wire to the passenger side under the removed scuff panel. Repeat step 2 on the passenger side using the yellow wire.

4. Adhere the black converter box in the spare tire compartment in an out of the way location using the double-sided tape provided. Secure any loose parts of the T-connector with the cable ties provided.

5. Route the black wire behind the felt trunk liner to the battery. The battery is located on the passenger side behind the back seat in the trunk. [H] Using a 10 mm socket remove nut on on both battery terminals. Remove the negative (-) battery cable. Connect the black power wire terminal ring to the positive (+) battery terminal. Reconnect the negative (-) battery wire. Insert the 10 AMP fuse into the inline fuse holder.

6. Re-install anything removed during install. Secure any loose wires using the cable ties provided.

**WARNING!**  
Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and/or personal injury.



56099