

# No-Drill System

No drilling into your vehicle fender required!


# 2015, GMC HD Dually Rear Mount Bracket Mounting Diagram & Instructions 756991

## GATORBACK

### IMPORTANT:

The manufacturer is not responsible for negligent use of vehicle with mud flaps installed, including over-tightening of screws and bolts causing damage to vehicle or mud flaps.


### TOOLS REQUIRED:



Electric or re-chargeable  
1/2" or 3/8" drill.



T27 screwdriver



1/2" wrench or  
socket driver



1/4" drill bit




Philips  
Screwdriver




Allen Wrench

### KIT CONTAINS: PARTS BAG #755934

a) (1) Mount Bracket,  
Rear, DS  
Part #755932



b) (1) Mount Bracket  
Rear, PS  
Part #755933



c) (14) Machine Screw SS  
#8-32 x 5/16" oval hd  
Part #012023



e) (4) Machine Screw SS  
M6-1x1-1/4" Button Head  
Part #014048



f) (14) Nut, T, SS, 3 Prong  
#8-32UNC x 1/4" Barrel  
Part #016028



g) (4) Flat Washer  
0.281" x 1"  
Part #018028



### INSTALLATION

For ease of installation, it is suggested that the wheel be removed.

1. Before you install your mud flap set, see the diagram and parts list for all necessary parts. Cut protective plastic and peel away from stainless steel. Start on driver's side.
2. Use the DS mount bracket to locate holes #9 to #13 and drill a 1/4" hole (5) from #9 to #13. (See diagram #1)




Diagram #1

3. Fasten the DS mount bracket to the rubber mud flap with the seven machine screws #8 x 5/16" and seven t-nut #8 in holes #1 to #4 and #9 to #11. (See diagram #1)
4. Remove the factory bolts #4 and #5 on the wheel well as shown on the diagram and discard. (See diagram #2)
5. Loosen factory bolt #6 approximately 1/4", then slide the opened slot hole #3 of the upper mount bracket into the factory bolt #6 and hold it in that position. (See diagram #2)
6. Now install two machine screws and two flat washers on holes #1 and #2 through the factory holes #4 and #5. Loosely secure at this point. (See diagram #2)
7. Square the flap with the tire and push the flap up against the wheel well.
8. Tighten all three screws/bolts on holes #1 to #3.




Diagram #2

- ✓ Check all fasteners for tightness. Repeat procedure on the other side.